GAUGES & METERS

ULTRASONIC MODBUS WATER METER FLANGE ENDED

COMPLY WITH ISO 4064-1 ISO 4064-2





SIDE VIEW

Wire material used: RS485 bus RVV4x (0.2-1mm²) shielded wire. _

	CON	COMPONENT PARTS			
STANDARD SPECIFICATIONS		EM	PARTS	MATERIAL	
Water Temperature 0°C < t :	≤ 30°C	1	Lid	Epoxy Coated Ductile Iron	
Operating Pressure < 1.6Mp	a 2	2	Sealed Register	PC+ABS+POM	
Operating Voltage DC 12 V		3	Communications	/	
Battery Lifespan 6 Years	4	4	Body	Epoxy Coated Ductile Iron	
Communication	c E	5	Impeller	ABS	
transmission rate 7000 D/.	(6	Flange	Epoxy Coated Ductile Iron	

FLOW RATE SPECIFICATIONS

CHICAHONS	-				
SIZE	QS Maximum	QP Nominal	Qt Transitional	Qmin Minimum	
(mm)	flow rate [m³/h]	flow rate [m³ /h]	flow rate [m³ /h]	flow rate [m³ /h]	
50	31.250	25.0	0.160	0.100	
65	50.000	40.0	0.256	0.160	
80	78.750	63.0	0.403	0.252	
100	125.000	100.0	0.640	0.400	
150	312.500	250.0	1.600	1.000	
200	500.000	400.0	2.560	1.600	
250	787.500	630.0	4.030	2.520	
300	1250.000	1000.0	6.400	4.000	
350	3125.000	1600.0	16.000	10.000	
400	3125.000	1600.0	16.000	10.000	
	SIZE (mm) 50 65 80 100 150 200 250 300 350 400	SIZE QS Maximum (mm) flow rate [m³ /h] 50 31.250 65 50.000 80 78.750 100 125.000 150 312.500 200 500.000 250 787.500 300 1250.000 350 3125.000 400 3125.000	SIZE QS Maximum QP Nominal (mm) flow rate [m³ /h] flow rate [m³ /h] 50 31.250 25.0 65 50.000 40.0 80 78.750 63.0 100 125.000 100.0 150 312.500 250.0 200 500.000 400.0 250 787.500 630.0 300 1250.000 1000.0 350 3125.000 1000.0 400 3125.000 1600.0	SIZE QS Maximum QP Nominal Qt Transitional (mm) flow rate [m³/h] flow rate [m³/h] flow rate [m³/h] 50 31.250 25.0 0.160 65 50.000 40.0 0.256 80 78.750 63.0 0.403 100 125.000 100.0 0.640 150 312.500 250.0 1.600 200 500.000 400.0 2.560 250 787.500 630.0 4.030 300 1250.000 1000.0 6.400 350 3125.000 1000.0 6.400 350 3125.000 1000.0 16.000 400 3125.000 1600.0 16.000	

DIMENSIONS								
SKU	L(mm)	D(mm)	H(mm)	K(mm)	N-Bolt(mm)	B(mm)	WEIGHT(kg)	PCS/CTN
WMSUN050F	200	165	219	125	4-M16	120	9.80	1
WMSUN065F	200	185	231	145	4-M16	120	11.40	1
WMSUN080F	225	200	249	160	8-M16	120	13.20	1
WMSUN100F	248	220	258	180	8-M16	120	16.30	1
WMSUN150F	300	285	297	240	8-M20	120	26.80	1
WMSUN200F	350	340	445	295	12-M20	120	-	1
WMSUN250F	450	405	495	355	12-M24	120	-	1
WMSUN300F	500	460	555	410	12-M24	120	-	1
WMSUN350F	550	520	595	470	16-M24	120	-	1
WMSUN400F	600	580	650	525	16-M27	120	-	1

*1] Ensure the water meter is installed in the correct water flow direction.

2] Always select the correct size and specification for the meter.

3] These water meters can be installed in either horizontal or vertical positions, but the correct installation

guidelines must be strictly followed. Failure to comply will result in damage to the meter and void the warranty. 4) Use exclusively for indoor installations.

Norika is constantly seeking product improvements. Therefore, its products are subject to change if deemed necessary.

Guideline for correct installations of ultrasonic modbus water meter (Flanged End)

Figure 1 – Horizontal Installation



If the reserved position for the meter on the welded flange is too large or if the flange is welded unevenly at an angle relative to the meter flange, do not forcibly tighten the bolts. Doing so may cause the meter body to break. The correct approach is to remove and reinstall the meter properly

Figure 2 – Horizontal Installation



When installing the meter horizontally, the integration instrument should be oriented upwards. If it is oriented to the side, the two transducers may not be on the same horizontal plane, allowing air to accumulate at the higher transducer and causing inaccurate or failed measurements.

Figure 3 - Horizontal Installation



When installed at a U-bend, the meter should be positioned at the lowest point. Air can accumulate at higher points in the pipe, leading to inaccurate or failed measurements.

Figure 4 - Horizontal Installation



When the meter is installed at a bend, ensure the straight pipe distance upstream of the meter is at least 5 times the pipe diameter, and the straight pipe distance downstream is at least 3 times the pipe diameter. Failure to maintain these distances may result in inaccurate measurements.

Figure 5 - Horizontal Installation



When a valve or other object is installed upstream of the meter, ensure there is a distance of at least 5 times the pipe diameter between the meter and the object. Failure to maintain this distance may result in inaccurate measurements.

Figure 6 - Vertical Installation



When installing the meter vertically, it must be placed on a straight pipe with water flowing upwards. Air can accumulate in the pipe at higher points due to gravity, leading to incomplete filling of the pipe and resulting in inaccurate or failed measurements.